

Installation and Operation Manual

**Thermo Scientific Thermolyne Furnace
Large Tabletop Muffle/
Atmosphere Controlled Ashing
Model Type: F30400**



LT1262X1 REV.C

© 2012 These operating instructions are protected by copyright. Rights resulting thereof, particularly reprint, photomechanical or digital post processing or reproduction, even in part, are only allowed with the written consent of

Thermo Fisher Scientific.

Trademarks

Thermo Scientific is a brand owned by Thermo Fisher Scientific Inc.

All trademarks mentioned in the operating instructions are the exclusive property of the respective manufacturers.

This regulation does not apply to reproductions for in-plant use.

The contents of this operating instructions manual may change at any time and without any prior notice.

Table of Contents

Safety Information	5
Alert Signals	5
Warning	5
General Specifications	7
Environmental Conditions	7
Introduction	8
Intended Use	8
General Usage	8
Principles of Operation	9
Unpacking	10
Installation	11
Site Selection	11
Electrical Connections	11
Operation, All Models	12
Power Switch	12
Cycle Light	12
Door Safety Switch	12
Single Setpoint Models w/OTP	13
Eurotherm 3216 Controller Operation	13
Basic Operation	13
Buttons and Indicators	13
To Change the Setpoint	14
To View the Display Units	14
Controller Parameters	14
Alarms	15
Sensor Break Protection	15
Over-Temperature Protection (OTP)	16
Tuning	16
Single Ramp & Dwell	17
Functions	17
Program Overview	17
SetPoint Rate Limit Setup	18
Running the Program	18
Holding the Program	18
Stopping the Program	18
Clearing the Flashing End	19
Verifying a Running Program	19
8 Segment & 4x16 Segment	20
Programmable Models w/OTP	20
Basic Operation	20
To Change the Setpoint	20
To View Display Units	21
Buttons and Indicators	21
Controller Parameters	22

Alarms.....	25
Sensor Break Protection	25
Over-Temperature Protection (OTP)	26
To Operate the Controller as a Single Setpoint Controller	26
Programming the Controller	26
Creating a New Program or Editing an Existing Program (4x16 Segment Programmable Models Only)	27
Setting the Target Setpoint (4x16 Segment Programmable Models Only).....	33
Running a Program (8 Segment Programmable Models)	33
Running a Program (4x16 Segment Programmable Models)	33
Holding a Program.....	34
Cancelling a Program.....	34
Tuning your Furnace	34
Gain Scheduling.....	35
Installation and Operation of Air Control.....	37
Installation.....	37
Furnace Loading.....	38
Preventative Maintenance.....	39
General Cleaning Instructions	39
Problem Solving	40
Maintenance and Servicing.....	43
Warning.....	43
To Replace a Heating Element.....	43
To Replace a Platinel II Thermocouple	44
To Replace Solid State Relay:.....	45
To Replace Door Switch (Microswitch).....	45
To Realign Door Strike	46
To Replace Control Module	47
Replacement Parts	48
Single Setpoint Models.....	48
8 Segment Programmable Models with OTP	48
4X16 Segment Programmable Models with OTP	49
Ordering Procedures.....	50
Wiring Diagrams	51

Safety Information

Alert Signals



Warning

Warnings alert you to a possibility of personal injury.



Caution

Cautions alert you to a possibility of damage to the equipment.



Note

Notes alert you to pertinent facts and conditions.



Hot Surface

Hot surfaces alert you to a possibility of personal injury if you come in contact with a surface during use or for a period of time after use.

Your Thermo Scientific Thermolyne furnace has been designed with function, reliability and safety in mind. It is your responsibility to install it in conformance with local electrical codes. For safe operation, please pay attention to the alert signals throughout the manual.

To avoid electrical shock, this furnace must:

1. Use a properly grounded electrical outlet of correct voltage and current handling capacity.
2. Disconnect from the power supply prior to maintenance and servicing.
3. Have the door switch operating properly.

To avoid burns, this furnace must:

1. Not be touched on the exterior or interior surfaces during use or for a period of time after use.

To avoid personal injury:

1. Do not use in the presence of flammable or combustible materials; fire or explosion may result. This device contains components which may ignite such material.
2. Refer servicing to qualified personnel.

Warning

Please note the following WARNINGS:

This warning is presented for compliance with California Proposition 65 and other regulatory agencies and only applies to the insulation in this product. This product contains refractory ceramic, refractory ceramic fiber or fiberglass insulation, which can produce respirable dust or fibers during disassembly. Dust or fibers can cause irritation and can aggravate pre-existing respiratory diseases. Refractory ceramic and refractory ceramic fibers (after reaching 1000°C) contain crystalline silica, which can cause lung damage (silicosis). The International Agency for Research on Cancer (IARC) has classified refractory ceramic fiber and fiberglass as possibly carcinogenic (Group 2B), and crystalline silica as carcinogenic to humans (Group 1).

SAFETY INFORMATION

The insulating materials can be located in the door, the hearth collar, in the chamber of the product or under the hot plate top. Tests performed by the manufacturer indicate that there is no risk of exposure to dust or respirable fibers resulting from operation of this product under normal conditions. However, there may be a risk of exposure to respirable dust or fibers when repairing or maintaining the insulating materials, or when otherwise disturbing them in a manner which causes release of dust or fibers. By using proper handling procedures and protective equipment you can work safely with these insulating materials and minimize any exposure. Refer to the appropriate Material Safety Data Sheets (MSDS) for information regarding proper handling and recommended protective equipment. For additional MSDS copies, or additional information concerning the handling of refractory ceramic products, please contact the Customer Service Department at (1-800-438-4851).

General Specifications

Models		F30420C, (-33), (-33-60-80), (-33-80), (-60-80) & (-80) F30430CM, (-33), (-33-60) & (-60)	F30428C, (-60-80) & (-80) F30438CM & (-60)
Overall Dimensions IN. (CM)	Width	21 1/2 (55)	21 1/2 (55)
	Height	29 1/2 (75)	29 1/2 (75)
	Depth	25 1/2 (65)	25 1/2 (65)
Chamber Dimensions IN. (CM)	Width	14 (35)	14 (35)
	Height	14 (35)	14 (35)
	Depth	14 5/8 (37)	14 5/8 (37)
Weight	Lbs. (KG)	188 (86)	188 (86)
Electrical Ratings	Volts	240	208
	Amps	22.9	26.4
	Watts	5500	5500
	Freq.	50/60	50/60
	Phase	1	1
Temperature Ratings °F (°C)	Cont.	400°F-1800°F* (204°C)-(982°C)	400°F-1800°F* (204°C)-(982°C)
	Intermittent	1800°F-2000°F (982°C)-(1093°C)	1800°F-2000°F (982°C)-(1093°C)

* The maximum continuous temperature for ashing furnaces (-60 models) is 1787°F (975°C).

Environmental Conditions

Operating: 17°C - 27°C; 20% to 80% relative humidity, non-condensing. Installation Category II (over-voltage) in accordance with IEC 664. Pollution Degree 2 in accordance with IEC 664.

Altitude limit: 2,000 meters.

Storage: -25°C to 65°C; ; 10% to 85% relative humidity.

Introduction

Intended Use

1. The Type 30400 Automatic and Programmable furnaces are general laboratory and heat treating furnaces. For optimum element life, the manufacturer recommends these furnaces for applications requiring temperatures from 400°F (204°C) to 1800°F (982°C) for continuous use, or temperatures from 1800°F (982°C) to 2000°F (1093°C) for intermittent use. Continuous use is operating the furnace for more than 3 hours and intermittent use is operating the furnace for less than 3 hours.
2. The unit consists of 1) a heating chamber; 2) an automatic proportioning digital set, digital read control with over-temperature protection and 3) a door interlock relay for user safety.
3. The Type 30400 Programmable furnace is designed to control a programmed temperature profile. The profile is in the format of ramps and dwell segments. The first ramp, RAMP 1, starts at the initial measured furnace temperature. This ramp is positive going at a programmed rate until the programmed level is reached. The setpoint will stay at this level for a period determined by the setting of DWELL 1. Additional positive or negative going ramps are now initiated starting at the level at the end of DWELL 1. When the second ramp reaches the second programmed level, the setpoint stays at that level for the duration of the segment. Depending upon the model ordered, additional ramp and dwell segments may be added. See specific model number in proceeding chart for total number of program segments.
4. The Type 30400 Automatic furnace is designed as a single set point controller which reaches and maintains one temperature value.



Note

When in the program RUN mode, the programmable controller serves to provide a programmed temperature profile as described earlier. When in the single setpoint automatic mode, the unit serves as an automatic temperature controller.

General Usage

Do not use this product for anything other than its intended usage.

MODEL NUMBER	DIGITAL COMMUM.	TOTAL NUMBER OF PROGRAMMABLE SEGMENTS	NUMBER OF STORED PROGRAMS
F30420C-33-80	NO	8	
F30420-33-60-80	NO	8	
F30420C-60-80	NO	8	
F30420C-80	NO	8	
F30428C-60-80	NO	8	
F30428C-80	NO	8	
F30430CM	YES	64	16 Segment Programs
F30430CM-33	YES	64	16 Segment Programs
F30430CM-33-60	YES	64	16 Segment Programs
F30430CM-60	YES	64	16 Segment Programs
F30438CM	YES	64	16 Segment Programs
F30438CM-60	YES	64	16 Segment Programs
F30420C	NO	0	
F30420C-33	NO	0	
F30428C	NO	0	

Principles of Operation

1. Furnace: The furnace chamber is heated by four electric resistance heaters which are embedded in a refractory material. The chamber is insulated with ceramic fiber insulation. The temperature is controlled by an automatic proportioning controller using a platinel thermocouple to feed back information. The control is located under the furnace chamber and is well insulated from the heat generated in the furnace chamber. The temperature is controlled by one of three types of controllers.

Unpacking

1. Visually check for any physical damage to the shipping container.
2. Inspect the equipment surfaces that are adjacent to any damaged area.
3. Open the furnace door and remove the packing material from inside the furnace chamber.
4. Vacuum the chamber prior to use to remove the insulation dust due to shipment.
5. Retain the original packaging material if reshipment is foreseen or required.

Installation

**Caution**

Be sure ambient temperature does not exceed 40°C (104°F). The recommended ambient temperature is 17°C - 27°C. Ambients above this level may result in damage to the controller.

**Caution**

Allow at least six inches of space between the furnace and any combustible surface. This permits the heat from the furnace case to escape so as not to create a possible fire hazard.

**Warning**

To avoid electrical shock, this furnace must always use a properly grounded outlet of correct voltage and current handling capacity.

Site Selection

Install furnace on a sturdy surface and allow adequate space for ventilation.

Electrical Connections

The electrical ratings are located on the specification plate on the back of the furnace. Consult customer service if your electrical service is different than those listed on the specification plate. Be sure the front power switch is in the OFF position before connecting the furnace to your electrical supply.

Operation, All Models

**Warning**

To avoid personal injury do not use in the presence of flammable or combustible chemicals; fire or explosion may result. This device contains components which may ignite such materials.

**Hot Surface**

Caution: Avoid Contact. To avoid burns, this furnace must not be touched on the exterior or interior surfaces during use or for a period of time after use.

**Warning**

Always wear safety glasses or a safety shield and high temperature gloves when loading or unloading the furnace. Long sleeved, fire retardant clothing and a fire retardant apron is also recommended.

**Warning**

To avoid electrical shock, the door safety switch must be operating properly.

Power Switch

Both the ON/OFF power switch and the digital display will illuminate when power is switched ON. The furnace will begin to heat to its controller's current setpoint. (See the instructions for your type of controller for information on checking and setting the setpoint.)


Cycle Light

The amber cycle light will illuminate whenever the power is being applied to the heating elements. The cycle light will turn on and off as the furnace reaches the setpoint.

Door Safety Switch

The door safety switch removes power from the heating elements when the door is opened. Open and close the door a few times; note that the amber CYCLE light will switch off when the door is opened. If this condition is not true, consult the Troubleshooting section before proceeding. This check must be done when the furnace is heating and the cycle light is illuminated.

Single Setpoint Models w/OTP



Eurotherm 3216 Controller Operation

The **single setpoint model w/ OTP** furnace controller is a single setpoint controller which provides a single digital display to indicate the current chamber temperature or setpoint temperature. This temperature controller features sensor break protection, self-tuning capability and over temperature protection (OTP) with an additional OTP relay device.

Basic Operation

When the controller is turned ON it will perform a short self-test and then display a default page. The measured value (process value) is found in the upper display and the setpoint is found in the lower display.

Buttons and Indicators

OP1 (Output 1): Illuminates when the output is ON (normally heating).

OP2 (Output 2): Illuminates when the output is ON (normally cooling).

OP4 (Output 4): Illuminates when the AA relay output is ON (will go on during an alarm situation).

PAGE button: Allows you to select a new list of parameters.

SCROLL button: Allows you to select a parameter within a list of parameters.

DOWN button: Allows you to decrease a value.

UP button: Allows you to increase a value.



Note

If at any time you want to return to the HOME DISPLAY, press PAGE button.

To Change the Setpoint

If you want to change the setpoint, press the **SCROLL** button until "**SP1**" is displayed. Press the UP or DOWN button until the desired setpoint value is displayed and then release the button. A few seconds after the button is released, the controller will accept the new value and is indicated by a brief flash of the display. Press **PAGE** button to return to HOME DISPLAY.

To View the Display Units

Press SCROLL until "UNITS" is displayed. The temperature units are also shown on the HOME DISPLAY to the right of the measured value (process value).

Temperature Units can be changed by pressing up and down buttons. Choice of Celsius (°C), Fahrenheit (°F), Kelvin (°K), Percentage (%), or None (nonE).

Controller Parameters

Home display

°C, °F, °K, %, or None: Temperature units in Celsius (default), Fahrenheit, Kelvin, Percentage (PErc), or None (nonE).

A1.DHI: Deviation high alarm.

A2.HI: High Limit alarm. Read Only.

A3.LO: Low Limit alarm. Read Only.

A.TUNE (tune): One-shot autotune enable.

WRK.OP: Working Output power. Read Only.

PV.OFS: Process Value Offset. Read Only.

SP.RAT: Ramp Rate Setpoint (default units is minutes).

DWELL: Time for dwell or delay (default units is minutes).

T.STAT: Timer Status. Active only when timer is active.

TM.CFG: Timer configuration.

Pid List

PB: Proportional band (in display units).

TI: Integral time in seconds.

TD: Derivative time in seconds.

ACCS List Code: Access code (Code needed to enter or change the other configuration parameters which are not normally accessible.) Not accessible.

Alarms

The controller will flash an alarm message in the home display if an alarm condition is detected.

A2.HI: Measured value full scale high alarm.

A1.DHI: Measured value deviation high alarm.

S.br: Sensor break: check that sensor is connected correctly.

LBR: Loop break: check that the heating circuits are working properly.

Ld.F: Heater Circuit fault: indication of either an open or short solid state relay, a blown fuse, missing supply or open circuit heater.

Sensor Break Protection

This controller provides sensor break protection in the event the thermocouple opens. If an open thermocouple condition occurs, the digital display will blink "S.br" and the power to the heating element will be shut OFF (Cycle light will extinguish).

Over-Temperature Protection (OTP)

The OTP will be in effect during any alarm condition when the temperature of the furnace has deviated beyond the limit. The “Deviation High” alarm is the only alarm value, which can be changed. To change it, press the SCROLL button until “A1.DHi” appears on the display. Press the UP or DOWN button to select the OTP value you desire. We recommend a value of 20° above your working temperature to provide protection for your workload. In addition to over-temperature protection, units containing a single setpoint controller w/OTP feature a mechanical OTP relay device, which disconnects power from the elements in an alarm condition.



Note

Furnace must be at ambient temperature before starting a tune. “Stat” and “Sp.rr” must be set to OFF or “tunE” will not initiate.

Tuning

This controller incorporates a self-tuning feature, which determines the optimum control parameters for the best temperature accuracy with your load and setpoint. Use this feature the first time you use your furnace and each time you change either your setpoint or the type of load you are heating. Thermo Fisher Scientific recommends you use this feature to provide the best temperature accuracy the controller can attain. To use the tuning feature:

1. Start tuning with the process at ambient temperature. This allows the tuner to calculate the low cutback and high cutback values more accurately.
2. Adjust the setpoint to your desired value.
3. Press the SCROLL button until display reads, “A.TUNE.”
4. Press the UP or DOWN button to select, “on.”
5. Press the PAGE button to return to the HOME DISPLAY. The display will alternately flash between “tunE” and the HOME DISPLAY while tuning is in progress.
6. The controller will then turn the heating on and off to induce an oscillation. When the measured value reaches the required setpoint the first cycle will end.
7. Tuning will be complete after two oscillation cycles and then the tuner will turn itself off.
8. Normal control function will resume after the controller calculates tuning parameters.



Note


Tune has completed when “tunE” stops flashing on display.

Single Ramp & Dwell

Functions


This type of controller has single ramp and dwell programming capabilities. The Ramp and Dwell can be configured to three different modes.

1. Mode 1 (DWELL) The dwell time begins once the setpoint is reached. The END TYPE action is executed when the dwell timer reaches the end.




MODE 1 (OPT. 1)

2. Mode 2 (DELY) The timer starts immediately upon instrument power-up, or when run is selected. The instrument remains in standby until the time has elapsed. After the time has elapsed, the instrument controls up to setpoint.



MODE 2 (OPT. 2)

3. Mode 3 (SF.ST) Starts automatically on power up. This is a soft-start function. If the PV is below the Soft Start Threshold, then the power is limited to the Soft Start Limit until the threshold is met.



MODE 3 (OPT. 3)



NOTE

The program must be stopped and the controller must be displaying the actual temperature before beginning the SetuP.

Program Overview

- A program mode can be set by changing the "TM.CFG" variable (in the 'Timer' menu) to "DWEL, DELY, or SF.ST."
- A Ramp rate may be set by changing the "SP.RAT" variable (in the 'SP' menu) to a value. The Ramp rate units are set with the "RAMPU" variable (in the 'SP' menu). The selections are Hour / Min / Sec.
- The Dwell time can be set by changing the "DWELL" variable (in the 'Timer' menu) to the desired value. Dwell time units are set with the "TM.RES" variable (in the 'Timer' menu). The selections are Hour / Min.
- The program Status can be set by changing the "T.STAT" variable to "run", "hold", or "res." This variable will start, hold, or stop the program.

SetPoint Rate Limit Setup

1. Press the **SCROLL** button until the “**SP.RAT**” (Ramp Rate) is displayed.
2. Set the desired Ramp rate with the UP or DOWN buttons, if the ramp to setpoint feature is needed.
If the Ramp rate is not needed, then set to “OFF” with the UP or DOWN buttons.
3. Press the **SCROLL** button until “**TM.CFG**” (Ramp & Dwell mode) will be displayed, select the desired mode with the UP or DOWN buttons (DWEL, DELY, or SF.ST).
4. Press the **SCROLL** button until “**DWELL**” will be displayed set the desired Dwell time with the UP or DOWN buttons.
5. Press the **PAGE** button and **SCROLL** button together until the Actual temperature is displayed.

Running the Program

1. Press the **SCROLL** button until “**T.STAT**” is displayed, set to “run” with the **UP and DOWN** buttons; or from the HOME DISPLAY, press UP and DOWN arrows together.
2. Press the **PAGE** button to display Actual temperature.

Holding the Program

1. Press the **SCROLL** button until “**T.STAT**” is displayed set to “hold” with the UP or DOWN buttons; or from the HOME DISPLAY, press **UP and DOWN** arrows together.
2. Press the **PAGE** button to display Actual temperature.

Stopping the Program

Press the **SCROLL** button until “**T.SAT**” is displayed set to “res” with the UP or DOWN buttons.

Clearing the Flashing End

Press the **PAGE** and **SCROLL** buttons at the same time.

Verifying a Running Program

Press the **SCROLL** button until "**T.SAT**" is displayed. The display will show "**run**" if the program is running, "**hold**" if it is paused or "**res**" if it is not running. Press the **PAGE** button to display Actual temperature.

8 Segment & 4x16 Segment Programmable Models w/OTP




Note

The controller will return to the HOME DISPLAY if left idle for more than a few seconds.



Note

Once the desired parameter has been selected, depressing either the UP or DOWN button will change the parameter value. In all cases, the value shown on the display is the current working value of that parameter.



4x16 & 8 Segment Programmable Models with OTP

The **8 segment programmable** controller consists of a microprocessor based three-mode PID (Proportional, Integral, and Derivative), programmable temperature controller with over-temperature protection and appropriate output switching devices to control the furnace. The digital readout continuously displays chamber (upper display) and setpoint (lower display) temperatures unless the SCROLL or PAGE button is depressed. The programmable controller can be used as a single setpoint controller or as a programmable controller. The 8 segment digital model enables eight segments of programming.

The **4x16 segment programmable** controller consists of a microprocessor based three-mode PID (Proportional, Integral, and Derivative), programmable temperature controller with over-temperature protection and appropriate output switching devices to control the furnace. The digital readout continuously displays chamber (upper display) and setpoint (lower display) temperatures unless the SCROLL or PAGE button is depressed. The programmable controller can be used as a single setpoint controller or as a programmable controller. The 4 program controller has four 16 segment programs.

Basic Operation

When the controller is turned ON, it will perform a short self-test and then change to the HOME DISPLAY. The HOME DISPLAY shows the measured temperature (process value) in the upper display and the desired value (setpoint) in the lower display.

To Change the Setpoint

If you want to change the setpoint, press the UP or DOWN button until the desired setpoint value is displayed in the lower display and then release the button.

To View Display Units

From the HOME DISPLAY press the SCROLL button. The display will briefly show the temperature units in °C/F/K and then return to the HOME DISPLAY. (If you require a different temperature unit call Customer Service.)

To View the % Output Power

From the HOME DISPLAY press the SCROLL button twice. This value is a read-only value and cannot be changed.

Buttons and Indicators

OP1 (Output 1): illuminates when the heating output of the temperature controller is on.

AUTO/MAN: (Auto/Manual Mode): when the controller is in the automatic mode the output automatically adjusts to keep the temperature or process value at the setpoint. The “AUTO” light will illuminate. The manual mode has been disabled through factory configuration. Call Customer Service for further information.

RUN/HOLD (Run/Hold button):

- Starts a program when pressed once—RUN light illuminates.
- Holds a program when pressed again—HOLD light illuminates.
- Cancels hold and continues running when pressed again—HOLD light is off and RUN light illuminates.
- Exits a program when the button is held down for two seconds—RUN and HOLD lights are off.
- At the end of a program the RUN light will flash.
- During holdback the HOLD light will flash.

PAGE button: allows you to choose a parameter from a list of parameters.

SCROLL button: allows you to choose a parameter within a list of parameters.

UP button: allows you to increase the value in the lower display.

DOWN button: allows you to decrease the value in the lower display.

Controller Parameters

Home Display

°C: measured temperature in Celsius. Temperature units can not be changed without entering the configuration. Contact Customer Service if a different temperature unit is required.

OP: % output power demand; displayed in lower display (cannot be changed).

C.id: Controller identification number.

PrG: Program number (displayed when a program is running; 4x16 programmable models only).

IdHi: Deviation High Alarm.

tunE: One-shot autotune enable.

run LiSt (Program Run List)

PrG: Currently running program (only used on 4x16 programmable models).

StAt: Displays the program status [OFF, run (running active program), hoLd (program on hold), HbAc (waiting for process to catch up), End (program completed)] in the lower display. The controller will default to "OFF."

FASt: Fast run through program (no/YES). The controller will default to "no."

SEG.d: Flash active segment type in the lower display of the home display (no/YES). The controller will default to "no."

ProG LiSt (Program Edit List)

PrG.n: Press the UP or DOWN ARROW to select the program number (program number will be displayed in lower display on 4x16 programmable models only).

Hb: Press the UP or DOWN ARROW to select the holdback type [OFF (disables holdback), Lo (deviation low holdback), Hi (deviation high holdback) or bAnd (deviation band holdback)] for the entire program. The controller will default to "OFF."

Hb.U: Press the UP or DOWN ARROW to select the holdback value (in display units).

rmP.U: Press the UP or DOWN ARROW to toggle between ramp units (SEc, min or Hour). Controller will default to "SEc."

dwL.U: Press the UP or DOWN ARROW to toggle between dwell units (SEc, min or Hour). Controller will default to "SEc."

Cyc.n: Press the UP or DOWN ARROW to set the number of program cycles (1 to 999 or cont). The controller will default to "cont."

SEG.n: Press the UP or DOWN ARROW to select the segment number (1-8 in 8 segment models, 1-16 in 4x16 models).

tYPE: Press the UP or DOWN ARROW to select the segment type [End (end of program), rmP.r = ramp rate (ramp to a specified setpoint at a set rate), rmP.t = ramp time (ramp to a specified temperature in a set time), dwELL (to maintain a constant temperature for a set time), StEP (climb instantaneously from current to specified temperature), cALL (to call a program as a subroutine, available only on 4x16 programmable models)]. The controller will default to "End." Other parameters used with tYPE include; tGt target setpoint), Rate (rate of temperature increase) and dur (time to target setpoint or time to dwell).

End.t: End segment type: dwELL (dwell continuous), rSEt (reset) and S OP (End Segment Output power level).

AL LiSt (Alarm List)

IdHi: Deviation High Alarm.

Atun LiSt: (Autotune List)

tunE: One-shot autotune enable.

drA: Adaptive tune enable.

drA.t: Adaptive tune trigger level in display units.
Range = 1 9999.

Pid LiSt

G.SP (Gain Setpoint): Is the temperature at which the controller switches from the (SEt1) PID values to the (SEt 2) PID values.

Pb: Proportional band in display units. (SEt 1)

ti: Integral time in seconds. (SEt 1)

td: Derivative time in seconds. (SEt 1)

Pb2: Proportional band. (SEt 2)

ti2: Integral time in seconds. (SEt 2)

td2: Derivative time in seconds. (SEt 2)

ACCS LiSt (Access List)

Access Code (Code needed to enter or change the other configuration parameters which are not normally accessible.) Not accessible.



Note

The following alarm messages are factory default settings and may vary if you have changed the configuration of your controller:

IDHi: = 50°C

2FSH = 1118°C (all models except -60)

2FSH = 1000°C (-60 models only)

Alarms

The controller will flash an alarm message in the home display if an alarm condition is detected.

IdHi: PV deviation high alarm.

2FSH: PV full scale high alarm.

LCr: load current low alarm.

HCr: load current high alarm.

S.br: Sensor break: check that sensor is connected correctly.

L.br: Loop Break: Check that the heating circuits are working properly.

Ld.F: Heater Circuit Fault: indication of either an open or short solid state relay, a blown fuse, missing supply or open circuit heater.

SSr.F: Solid state relay failure indications in a solid state relay: indicates either an open or short circuit in the SSR.

Htr.F: Heater failure: Indication that there is a fault in the heating circuit: indicates either a blown fuse, missing supply or open circuit heater.

Sensor Break Protection

This controller provides sensor break protection in the event the thermocouple opens. If an open thermocouple condition occurs, the digital display will Blink "S.br" and the power to the heating element will be shut OFF (Cycle light will extinguish).

Over-Temperature Protection (OTP)

The OTP will be in effect during any alarm condition when the temperature of the furnace has deviated beyond the limit. The “Deviation High” alarm is the only alarm value which can be changed. To change it, press the SCROLL button until “idHi” appears on the display. Press the UP or DOWN button to select the OTP value you desire. We recommend a value of 20° above your working temperature to provide protection for your workload.

To Operate the Controller as a Single Setpoint Controller

1. Switch the circuit breaker to the “ON” position. The setpoint temperature presently set in the controller will appear in the lower display. (The upper display indicates the actual chamber temperature.)
2. To change the setpoint, press the UP or DOWN button until the desired setpoint value is displayed; then release the button.
3. The furnace will begin to heat if the new set- point temperature is higher than the present chamber temperature.

Programming the Controller

The controller is capable of varying temperature or process value with time through programming. A program is stored as a series of segments and can be run once, repeated a set number of times or run continuously. To create a customized program using the controller parameters listed under “Controller Parameters” at the beginning of this section, follow the procedures outlined in the proceeding sections of this manual.

Creating a New Program or Editing an Existing Program (4x16 Segment Programmable Models Only)

The same steps are used when creating a new program and editing an existing program with the exception being that a new program starts with all its segments set to End in the tYPE parameter.

Temporary changes can be made to these parameters when the program is in the hold state but permanent changes must be made in the reset state. Follow the steps below to create or edit a program.

1. Press the PAGE button until you reach the program list (ProG LiSt).
2. Press the SCROLL button until display reads, "PrG.n."
3. Press the UP or DOWN button to select a number for a new program or to edit an existing program.

Hb: Holdback

Holdback consists of a value and a type. If the measured value lags behind the setpoint by an undesirable amount during a ramp or dwell, the holdback feature can be used to freeze the program at its current state (the HOLD light will flash). The program will resume when the error comes within the holdback value.

OFF: holdback is disabled.

Lo (Deviation Low Holdback): holds the program back when process variable deviates below the setpoint by more than the holdback value.

Hi (Deviation High Holdback): holds the program back when process variable deviates above the setpoint by more than the holdback value.

bAnd (Deviation Band Holdback): combines the features of the high and low deviation holdback in that it holds the program back when the process variable deviates above or below the setpoint by more than the holdback value.

To set the holdback type:

1. Press the PAGE button until you reach the program list (ProG LiSt).
2. Press the SCROLL button until display reads, "Hb."
3. Press the UP or DOWN button to toggle between "bAnd, Hi, Lo and OFF."



Note

The value set in this parameter is always for the entire program.

Hb U: Holdback Value

To set the holdback value:

1. Press the PAGE button until you reach the program list (ProG LiSt).
2. Press the SCROLL button until display reads, "Hb.U."
3. Press the UP or DOWN button to enter a holdback value.

rmP.U: Setting Ramp Units

Ramp units are time units which are used in "rmP.r" segments (ramp to a setpoint at degrees per second, minute or hour) and "rmP.t" segments (ramp to setpoint in a specific amount of time). See "Setting the Segment Type" for an explanation on how to set a ramp segment.

1. Press the PAGE button until you reach the program list (ProG LiSt).
2. Press the SCROLL button until display reads, "rmP.U."
3. Press the UP or DOWN button to toggle between seconds, minutes and hours.

dwL.U: Setting Dwell Units

Dwell units are time units which are used in “dwELL” segments (amount of time to remain at a specific temperature). See “Setting the Segment Type” for an explanation on how to set a dwell segment.

1. Press the PAGE button until you reach the program list (ProG LiSt).
2. Press the SCROLL button until display reads, “dwL.U.”
3. Press the UP or DOWN button to toggle between seconds, minutes and hours.

CYC.n: Setting the Number of Cycles

Set the number of times a group of segments or programs are to be repeated by following the steps listed below.

1. Press the PAGE button until you reach the program list (ProG LiSt).
2. Press the SCROLL button until display reads, “CYC.n.”
3. Press the UP or DOWN button to select the number of cycles you want to run or, press the DOWN button to select “cont.” so the program will run continuously.



Note

The program ramp rate is designed to reduce the heatup rate or cooling rate that the furnace normally exhibits. When not using this feature, the furnace will operate at its maximum heating and cooling capability.



Note

When the program ramp has ended or has been reset, the furnace will continue to maintain setpoint temperature. It will not cool to ambient temperature unless the setpoint is set to ambient temperature by the program or by the operator.

Setting the Segment Type

There are five segment types. Proceed with the following steps according to the type of segment you have selected.

rmP.r (Ramp)

To ramp linearly at a set rate to a specified temperature:

1. Press the PAGE button until you reach the program list (ProG LiSt).
2. Press the SCROLL button until display reads, “tYPE.”
3. Press the UP or DOWN button until display reads, “rmP.r.”

Steps 4 and 5 are used in the 4 program model only. If you are using an 8 segment program, skip to step 6.

4. Press the SCROLL button until display reads "Hb."
5. Press the UP or DOWN button to toggle between "bAnd, Hi, Lo and OFF."
6. Press the SCROLL button until display reads, "tGt."
7. Press the UP or DOWN button to set a target setpoint.
8. Press the SCROLL button until display reads,"rAtE."
9. Press the UP or DOWN button to select a value in ramp units (seconds, minutes or hours; set in the "rmP.U" parameter).

rmP.t

To ramp to a specified temperature at a set time:

1. Press the PAGE button until you reach the program list (ProG LiSt).
2. Press the SCROLL button until display reads, "tYPE."
3. Press the UP or DOWN button until display reads, "rmP.t."
4. Press the SCROLL button until display reads, "tGt."
5. Press the UP or DOWN button to set a target setpoint.
6. Press the SCROLL button until display reads, "dur."
7. Press the UP or DOWN button to select a time in ramp units (seconds, minutes or hours; set in the "rmP.U" parameter).

dwELL

To maintain a constant temperature for a specified time:

1. Press the PAGE button until you reach the program list (ProG LiSt).
2. Press the SCROLL button until display reads, "tYPE."
3. Press the UP or DOWN button until display reads, "dwELL."
4. Press the SCROLL button until display reads, "dur."
5. Press the UP or DOWN button to select a time in dwell units (seconds, minutes or hours; set in the "dwL.U" parameter).

StEP

To climb instantaneously from the current temperature to a specified temperature.

1. Press the PAGE button until you reach the program list (ProG LiSt).
2. Press the SCROLL button until display reads, tYPE."
3. Press the UP or DOWN button until the display reads, "StEP."
4. Press the SCROLL button until display reads, "tGt."
5. Press the UP or DOWN button to set a target setpoint.

cALL (Running Multiple Programs; 4x16 Segment Programmable Models Only)

To call a program as a subroutine:

If you want to run multiple programs, you can program the controller to "call" or link one program to another. This makes it possible to run one program at any time during another program and also return to the original program if desired.

1. Press the PAGE button until you reach the program list (ProG LiSt).
2. Press the SCROLL button until display reads, "tYPE."
3. Press the UP or DOWN button until display reads, "cALL."
4. Press the SCROLL button until display reads, "PrG.n."
5. Press the UP or DOWN button to select a program number to be linked.
6. Press the SCROLL button until display reads, "CYC.n."
7. Press the UP or DOWN button to select the number of cycles the linked program is to be run.

End

To end or repeat a program:

1. Press the PAGE button until you reach the program list (ProG LiSt).
2. Press the SCROLL button until display reads, "tYPE."
3. Press the UP or DOWN button until display reads, "End."
4. Press the SCROLL button until display reads, "End.t."
5. Press the UP or DOWN button to toggle between "dwELL" (an indefinite dwell), "S OP" (End Segment Output Power) and "rSET" (reset).

Setting the Target Setpoint (4x16 Segment Programmable Models Only)

1. Press the PAGE button until you reach the program list (ProG LiSt).
2. Press the SCROLL button until display reads, "tGt."
3. Press the UP or DOWN button to set the target setpoint temperature.

Running a Program (8 Segment Programmable Models)

To run a program, press the RUN/HOLD button. (The RUN light will illuminate.)

Running a Program (4x16 Segment Programmable Models)

To run a program, press the RUN/HOLD button. (The RUN light will illuminate) or:

1. Press the PAGE button until you reach the run list (run LiSt).
2. Press the SCROLL button until display reads, "PrG."
3. Press the UP or DOWN button to select the program number you want to run.
4. Press the RUN/HOLD button once to start the program. (The RUN light will illuminate.)



Note

Display will flash “tu.ER” if an error occurs during tuning. To clear the error and restart tuning, simultaneously press the PAGE and SCROLL buttons and follow the steps outlined in “Autotuning.”



Note

To stop the tuning function, simultaneously press the PAGE and SCROLL buttons.

Holding a Program

To put a running program on hold, press the RUN/HOLD button. (The HOLD light will illuminate.)

Cancelling a Program

To cancel a program, hold the RUN/HOLD button down until the RUN and HOLD lights go off.

Tuning your Furnace

The purpose of tuning your furnace is to match the characteristics of your controller to the characteristics of the process being controlled. Good control is evidenced by: stable, straight-line control of the setpoint temperature with no fluctuations; No overshoot or undershoot of the setpoint temperature; rapid restoration of the setpoint temperature when external disturbances cause deviations from the setpoint.

This controller has automatic tuning features which install optimum tuning parameters to give the best temperature accuracy. No manual loading of tuning parameters is needed. We recommend that you tune the furnace to your specific application to obtain the best results. To provide the best temperature accuracy possible, use these features when you install your furnace and whenever you change your application or procedure.

Tuning Error

The display will flash “tu.ER” if an error occurs during tuning. To clear the error and restart tuning, simultaneously press the PAGE and SCROLL buttons and follow the steps outlined in “Autotuning.”

Gain Scheduling

G.SP: Gain Scheduling

Gain scheduling is the automatic transfer of control between two sets of PID values. The 2416 controller does this at a presettable process value. Gain scheduling is used for difficult control processes which show large changes in their response time or sensitivity at high or low temperatures, or when heating or cooling.

The G.SP gain schedule setpoint is factory set at 700° C. The G.SP must be adjusted to 200°C from the desired setpoint temperature when tuning.

Setting the Transfer Point

If gain scheduling has been enabled, "G.SP will appear at the top of the PID list. This sets the value at which the transfer will occur. When the process value is below this level, PID1 will be active and when it is above, Pid2 will be active. Set a value between the control regions that show the greatest change to achieve the best point of transfer.

Tuning

The two sets of PID values can be manually set or automatically tuned. To tune automatically you must tune above and below the transfer point G.SP. If the process value is below the transfer point G.SP, the calculated values will automatically be inserted into the (SEt 1) set and if the process value is above G.SP, the calculated values will automatically be inserted into the (SEt 2).

Autotuning

The Autotune feature automatically sets up the PID values in the control parameters to suit new process conditions.

To tune your furnace using autotuning:

1. Load your furnace with a load similar to your normal load and close the door.
2. Set the setpoint temperature.
3. Press the PAGE button until the display reads, "Atun LiSt."
4. Press the SCROLL button until "tunE OFF" is displayed.
5. Press the UP or DOWN button to select "on."
6. Simultaneously press the PAGE and SCROLL buttons to return to the HOME DISPLAY. The display will flash "tunE" while tuning is in progress.

Adaptive Tuning

Adaptive tuning continuously evaluates tuning parameters. Adaptive tuning automatically installs new values if better accuracy is possible. Adaptive tuning should be used when the characteristics of a process change due to load or setpoint changes or, in a process that can not handle the oscillation caused by a one-shot tune.

To tune your furnace using adaptive tuning:

1. Load your furnace with a load characteristic of those you intend to heat in it.
2. Press the PAGE button until display reads, "Atun LiSt."
3. Press the SCROLL button until "drA OFF" is displayed.
4. Press the UP or DOWN button to select "on."
5. Press the SCROLL button until "drA.t" is displayed.
6. Press the UP or DOWN button until the desired trigger value is achieved.

Installation and Operation of Air Control

**Models F30420-33-60-80, F30420C-60-80,
F30428C-60-80, F30430CM-33-60, F30430CM-
60, F30438CM-60**



Note

Ashing furnaces -60 models contain a feature to provide air (or inert gas) flow within the furnace chamber.



Note

A pressurized air line with a minimum working pressure range of 0 to 40 psi is required.



Note

If furnace is to be used regularly, the airline regulator may be left open to 30 psi.



Note

Appropriate exhaust must be provided to remove smoke and gases produced in an ashing procedure.

Installation

Compressed air hook-up

1. A 0.250 inch tube fitting is located at the rear of the furnace.
2. Using 0.250 inch I.D. rubber tubing, connect a length of tubing from this input fitting to a corresponding 0.250 inch fitting located on the regulated side of a pressurized air service line.
3. Prior to making connections at the regulator, insure that the regulator is turned fully closed (0 psi).
4. Turn flow control valve located at the bottom of the flow meter (front control panel) fully clockwise to closed position.
5. Turn regulator to maximum output pressure of 30 psi. Check for any leaks at connection points of connecting tubing.
6. Open flow control valve slowly until ball in flow meter reads between 40 to 45 liters per minute flow rate.
7. Open furnace door and check that air is exhausting from the manifold located at the bottom rear of the chamber.
8. Turn flow control valve to off (fully clockwise).

Exhaust tubing hook-up

Using accessory tubing (part number AY408X1A for furnace temperatures less than 975°C, part number AY718X1 for furnace temperatures of 975°C or greater) or equal quality 2.5" I.D. tubing appropriate for the temperatures at which you will operate your furnace, connect flexible tubing from vent port at top of furnace case to an appropriate negative pressure exhaust system. This exhaust system must be capable of handling smoke and gases produced in an ashing procedure.

Furnace Loading



Note

Failure to connect the exhaust port to an appropriate exhaust system will result in smoke and gases filling the work area. Without the connection, gases and smoke will escape around the door seal and at the rear of the furnace.



Caution

Do not overload your furnace chamber. If the load is to be heated uniformly it should not occupy more than two-thirds of the furnace chamber. Failure to observe this caution could result in damage to furnace components.

- For best results, use only the center two-thirds of the furnace chamber.
- Use Hearth plate to elevate load when placing on bottom heating element. This prevents bottom heating element from overheating and burning out. (Part Numbers PHX1 & PHX2)
- If you are heating a number of small parts, spread them throughout the center of the furnace chamber.
- Keep objects away from thermocouple.
- Use insulated tongs and mittens when loading and unloading furnace.
- Always wear safety glasses.

Preventative Maintenance

This unit is equipped with a venting system on the top of the furnace. This is for the removal of fumes from the chamber of the unit. Contamination is a major cause of element failure, therefore, removes all fume forming material before heating. (e.g. clean cutting oil from tool steel).

Housekeeping is vital to your electric furnace - KEEP IT CLEAN. Run your furnace up to 1600°F empty occasionally to burn off the contamination that may exist on the insulation and elements. Maintain 1600°F for at least 4 hours to insure complete ashing of foreign materials. Element life is reduced somewhat by repeated heating and cooling. If the furnace is to be used again within a few hours, it is best to keep it at the operating temperature or at a reduced level such as 500°F (260°C).

General Cleaning Instructions

Wipe exterior surfaces with lightly dampened cloth containing mild soap solution.

Problem Solving

The Problem Solving section is intended to aid in defining and correcting possible service problems. When using the chart, select the problem category that resembles the malfunction. Then proceed to the possible causes category and take necessary corrective action.

Problem	Probable Causes	Corrective Action
The cycle light does not illuminate.	The furnace is not connected to power supply. ON and OFF power switch is defective. Door switch defective. Incorrect power source. Defective circuit breaker.	Check furnace connection to power source. Replace power switch. Realign door strike or replace door safety switch. Check power source. Replace circuit breaker.
The furnace does not heat.	No power. Defective electrical hookup. Thermocouple has oxidized and opened the circuit. Controller malfunction. Two or more heating elements burned out. Door switch malfunction. Defective safety relay. Defective solid state relay (SSR).	Check power source and fuses or breakers. Repair electrical hookup. Replace thermocouple. Contact customer service. Replace defective elements. Realign door strike or replace door safety switch. Replace safety relay. Replace SS relay.

Problem	Probable Causes	Corrective Action
Slow heatup.	Low line voltage. Heavy load in chamber. Wrong heating element. One or more heating elements are burned out. Wired improperly.	Install line of sufficient size and proper voltage (Isolate furnace from other electrical loads). Lighten load in chamber to allow heat to circulate. Install proper element. Replace burned out elements. Check wiring diagram for correct wiring of your furnace.
Door switch does not cut power to the furnace chamber.	Door switch is not functioning. Safety relay malfunction.	Realign door strike or replace door safety switch. Replace safety relay.
Repeated element burnout.	Overheating furnace. Heating harmful materials.	Do not exceed the maximum operating temperature of furnace or recommended continuous intermittent use values. Enclose material in container. Clean up spills on chamber. Ventilate chamber by leaving door cracked slightly open when heating known harmful reagents.

PROBLEM SOLVING

Problem	Probable Causes	Corrective Action
	Contamination present from previous burnout. Wired improperly.	Clean and/or replace insulation material. Check wiring diagram for correct wiring of your furnace.
Inaccurate.	Oxidized or contaminated thermocouple. Poor thermocouple connections. Improper loading. Poor ventilation of base. Control out of calibration.	Replace thermocouple. Tighten connections. Use proper loading procedures. Clear area around furnace base. Contact customer service.

Maintenance and Servicing

**Warning**

Refer servicing to qualified personnel.

**Warning**

Replace fuses with same type and rating.

**Warning**

This product contains refractory ceramic, refractory ceramic fiber or fiberglass insulation, which can produce respirable dust or fibers during disassembly. Dust or fibers can cause irritation and can aggravate preexisting respiratory diseases. Refractory ceramic and refractory ceramic fibers (after reaching 1000°C) contain crystalline silica, which can cause lung damage (silicosis). The International Agency for Research on Cancer (IARC) has classified refractory ceramic fiber and fiberglass as possibly carcinogenic (Group 2B), and crystalline silica as carcinogenic to humans (Group 1).

**Warning**

To avoid electrical shock, this furnace must always be disconnected from the power supply prior to maintenance and service.

Perform only maintenance described in this manual. Contact an authorized dealer or our factory for parts and assistance.

Warning

Please note the following WARNINGS:

This warning is presented for compliance with California Proposition 65 and other regulatory agencies and only applies to the insulation in this product. This product contains refractory ceramic, refractory ceramic fiber or fiberglass insulation, which can produce respirable dust or fibers during disassembly. Dust or fibers can cause irritation and can aggravate preexisting respiratory diseases. Refractory ceramic and refractory ceramic fibers (after reaching 1000°C) contain crystalline silica, which can cause lung damage (silicosis). The International Agency for Research on Cancer (IARC) has classified refractory ceramic fiber and fiberglass as possibly carcinogenic (Group 2B), and crystalline silica as carcinogenic to humans (Group 1).

The insulating materials can be located in the door, the hearth collar, in the chamber of the product or under the hot plate top. Tests performed by the manufacturer indicate that there is no risk of exposure to dust or respirable fibers resulting from operation of this product under normal conditions. However, there may be a risk of exposure to respirable dust or fibers when repairing or maintaining the insulating materials, or when otherwise disturbing them in a manner which causes release of dust or fibers. By using proper handling procedures and protective equipment you can work safely with these insulating materials and minimize any exposure. Refer to the appropriate Material Safety Data Sheets (MSDS) for information regarding proper handling and recommended protective equipment. For additional MSDS copies, or additional information concerning the handling of refractory ceramic products, please contact the Customer Service Department at 1-800-438-4851.

To Replace a Heating Element

- a. Disconnect furnace from power supply.
- b. Remove the back terminal cover of the furnace (Note placement and connections of wires).

- c. Loosen the screws and nuts on the terminals of the element to be replaced.
- d. Open the door and pull the defective element out.
- e. Slide the new element into place, threading the leads through the insulating porcelain bushing on the back of the furnace.
- f. Cut off any excess lead wire. Be careful not to nick element lead wires. Reinstall terminal connections and tighten screws and nuts securely.
- g. Replace the back terminal cover.
- h. Reconnect furnace to power supply.
- i. Test operation of furnace.

To Replace a Platinel II Thermocouple

- a. Disconnect furnace from power supply.
- b. Remove the back terminal cover of the furnace. (Note placement and connection of T/C lead wires).
- c. Remove the screws on the thermocouple terminals and pull the thermocouple straight out.
- d. Insert the new thermocouple into the furnace with colored beaded lead connected to the positive (+) marked terminal and other lead to negative (-) terminal.
- e. Secure connections with screws removed earlier.
- f. Replace the back terminal cover.
- g. Reconnect the furnace to power supply.
- h. Test operation of furnace.

To Replace Solid State Relay:

- a. Disconnect furnace from power supply.
- b. Remove the screws on the front dial and the screws on the lower back cover.
- c. Remove the upper back cover.
- d. Disconnect the element lead wires and one ground wire from back of furnace. Also, disconnect T/C lead wire from terminal block. (Note placement and connection of wires).
- e. Slide control section forward and disconnect two wires from door switch. (Note placement and connection of wires).
- f. Control section can now be removed from furnace housing.
- g. Disconnect the wires from the relay and remove relay. (Note placement and connection of wires).
- h. Install new relay.
- i. Reverse steps a - e to reassemble furnace.
- j. Test operation of furnace.

To Replace Door Switch (Microswitch)

- a. Disconnect furnace from power supply.
- b. Remove the screws on the front dial and the screws on the lower back cover.
- c. Remove the upper back cover.
- d. Disconnect the element lead wires and one ground wire from back of furnace. Also, disconnect the lead wire from terminal block (note placement and location of wires).

- e. Slide the control section forward.
- f. Disconnect the wires from the door switch. (Note connection and placement of wires to Microswitch).
- g. Control section can now be removed from furnace housing.
- h. Remove the two screws and nuts from the Microswitch.
- i. Insert new Microswitch and secure with screws and nuts removed in Step h.
- j. Slide control section back and replace the wires on the door switch.
- k. Reverse steps b, c, d and e to reassemble furnace.
- l. Reconnect to power supply.
- m. Test operation of door switch. (To realign door strike, see To Realign Door Strike).

To Realign Door Strike

- a. Disconnect furnace from power supply.
- b. Loosen the screws which retain the door strike on the bottom left side of the door.
- c. Move the bracket closer to the furnace to make strike engage sooner. Move bracket further away to make strike engage later. (Lightly tighten screws between each adjustment to hold bracket while you test the strike.)
- d. The door switch should click when the door is approximately 1" from being completely closed.
- e. Tighten screws when bracket is positioned correctly.

- f. Reconnect to power supply.
- g. To test the operation of the door strike: turn the power switch on, set the control to a setting high enough to keep the control from cycling, open and close the door; the cycle light should switch on when the door is approximately 1" from being closed.

To Replace Control Module

- a. Gently pry the retaining tabs on both sides out, and then pull the control straight out of the sleeves. Install the new controller to the sleeve.

Replacement Parts

Single Setpoint Models

F30420C, F30420C-33, F30428C

<u>PartNumber</u>	<u>Description</u>	<u>Quantity</u>	<u>Notes</u>
CAX99	Line filter	1	"-33" model only
CA1249X1	Capacitor	1	"-33" model only
CN71X187	Controller	1	All models
EL412X1	Element (top)	1	208V model
EL412X2	Element (bottom)	1	208V model
EL412X3	Element (side)	2	208V model
EL412X4	Element (top)	1	240 V model
EL412X5	Element (bottom)	1	240 V model
EL412X6	Element (side)	2	240 V model
FA1262X1	Fan	1	All models
PLX82	Pilot light	1	All models
RYX37	S.S. relay	1	All models
RYX62	Mechanical relay	1	All models
SWX103	Circuit breaker	1	All models
SWX144	Power switch	1	All models
SWX163	Door switch	1	All models
TC412X1A	Thermocouple	1	All models
TRX96	Terminal block	1	All models
TRX178	Terminal block	1	All models

8 Segment Programmable Models with OTP

F30420C-33-80, F30420-33-60-80, F30420C-60-80, F30420C-80, F30428C-60-80, F30428C-80

<u>PartNumber</u>	<u>Description</u>	<u>Quantity</u>	<u>Notes</u>
CAX98	Line Filter	1	"-33" model only
CA1249X1	Capacitor	1	"-33" model only
CN71X89	Controller	1	F30420C-38-80, F30420C-80, F30428C-80
CN71X91	Controller	1	F30420-33-60-80, F30420C-60-80, F30428C-60-80
EL412X1	Element (top)	1	208V model
EL412X2	Element (bottom)	1	208V model
EL412X3	Element (side)	2	208V model
EL412X4	Element (top)	1	240 V model
EL412X5	Element (bottom)	1	240 V model
EL412X6	Element (side)	2	240 V model
FA1262X1	Fan	1	All models
SWX103	Circuit breaker	1	All models
PLX82	Pilot light	1	All models
RYX37	S.S. relay	1	All models

RYX62	Mechanical relay	1	All models
SWX144	Power switch	1	All models
SWX163	Door switch	1	All models
TRX96	Terminal block	1	All models
TRX178	Terminal Block	1	All models
TC412X1A	Thermocouple	1	All models

4X16 Segment Programmable Models with OTP

F30430CM, F30430CM-33, F30430CM-33-60, F30430CM-60, F30438CM, F30438CM-60

<u>PartNumber</u>	<u>Description</u>	<u>Quantity</u>	<u>Notes</u>
CAX99	Line Filter	1	"-33" model only
CA1249X1	Capacitor	1	"-33" model only
CN71X90	Controller	1	F30430CM, F30430CM-33, F30438CM
CN71X92	Controller	1	F30430CM-33-60, F30430CM-60, F30438CM-60
EL412X1	Element (top)	1	208V model
EL412X2	Element (bottom)	1	208V model
EL412X3	Element (side)	2	208V model
EL412X4	Element (top)	1	240 V model
EL412X5	Element (bottom)	1	240 V model
EL412X6	Element (side)	2	240 V model
FA1262X1	Fan	1	All models
SWX103	Circuit breaker	1	All models
PLX82	Pilot light	1	All models
RYX37	S.S. relay	1	All models
RYX62	Mechanical relay	1	All models
SWX144	Power switch	1	All models
SWX163	Door switch	1	All models
TRX96	Terminal block	1	All models
TRX178	Terminal Block	1	All models
TC412X1A	Thermocouple	1	All models

Ordering Procedures

Please refer to the Specification Plate for the complete model number, serial number, and series number when requesting service, replacement parts or in any correspondence concerning this unit.

All parts listed herein may be ordered from the **Thermo Scientific** dealer from whom you purchased this unit or can be obtained promptly from the factory. When service or replacement parts are needed we ask that you check first with your dealer. If the dealer cannot handle your request, then contact our Customer Service Department at 800-438-4851.


Prior to returning any materials, please contact our Customer Service Department for a "Return Materials Authorization" number (RMA). Material returned without an RMA number will be refused.

SINGLE SETPOINT CONTROL

WIRING DIAGRAM

DIAGRAM COMPONENT LIST

REF. NO.	DESCRIPTION	MODEL NO. AND OUR PART NO.(s)	
		F30420C	F30420C-33
B1482	BLOWER FAN	FA1262X1	FA1262X1
C41	CAPACITOR		CA1249X1
C81	CIRCUIT BREAKER	SWX103	SWX103
CN1	CONTROL	CN71X187	CN71X187
D81	PILOT LIGHT	PLX82	PLX82
FL1	FILTER, EMI		CAX39
H1	HEATING ELEMENT	EL412X4	EL412X4
H2	HEATING ELEMENT	EL412X5	EL412X2
H3	HEATING ELEMENT	EL412X6	EL412X3
H4	HEATING ELEMENT	EL412X6	EL412X3
RY1	SOLID STATE RELAY	RYX37	RYX37
RY2	RELAY, DPST, N.O.	RYX62	RYX62
S1	SWITCH	SWX144	SWX144
S2	DOOR SWITCH	SWX163	SWX163
TB1	TERMINAL BLOCK	TRX178	TRX178
TB2	TERMINAL BLOCK	TRX96	TRX96
TC1	THERMOCOUPLE	TC412X1A	TC412X1A




SEGMENT PROGRAMMABLE CONTROL

WIRING DIAGRAM

DIAGRAM COMPONENT LIST

REF NO.	DESCRIPTION	MODEL NO. AND OUR PART NO.(S)	F3042C-33-80	F3042C-33-80-80	F3042C-40-80	F3042C-40-80-80	F3042C-40-80-80-80	F3042C-40-80-80-80-80	F3042C-40-80-80-80-80-80
①	B1&B2 BLOWER FAN	FA1262X1	FA1262X1	FA1262X1	FA1262X1	FA1262X1	FA1262X1	FA1262X1	FA1262X1
②	CA1 CAPACITOR	CA1249X1	CA1249X1	CA1249X1	CA1249X1	CA1249X1	CA1249X1	CA1249X1	CA1249X1
	CB1 CIRCUIT BREAKER	SWX103	SWX103	SWX103	SWX103	SWX103	SWX103	SWX103	SWX103
	CN1 CONTROL	CN71X89	CN71X89	CN71X89	CN71X89	CN71X89	CN71X89	CN71X89	CN71X89
	DS1 PILOT LIGHT, NEON	PLX82	PLX82	PLX82	PLX82	PLX82	PLX82	PLX82	PLX82
	FL1 FILTER, EMI	CAX99	CAX99	CAX99	CAX99	CAX99	CAX99	CAX99	CAX99
	H1 HEATING ELEMENT	EL412X4	EL412X4	EL412X4	EL412X4	EL412X4	EL412X4	EL412X4	EL412X4
	H2 HEATING ELEMENT	EL412X5	EL412X5	EL412X5	EL412X5	EL412X5	EL412X5	EL412X5	EL412X5
	H3 HEATING ELEMENT	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6
	H4 HEATING ELEMENT	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6
	RY1 SOLID STATE RELAY	RYX37	RYX37	RYX37	RYX37	RYX37	RYX37	RYX37	RYX37
	RY2 RELAY, DPST, N.O.	RYX62	RYX62	RYX62	RYX62	RYX62	RYX62	RYX62	RYX62
	S1 SWITCH	SWX143	SWX143	SWX143	SWX143	SWX143	SWX143	SWX143	SWX143
	S2 DOOR SWITCH	04246	04246	04246	04246	04246	04246	04246	04246
	TB1 TERMINAL BLOCK	TRX178	TRX178	TRX178	TRX178	TRX178	TRX178	TRX178	TRX178
	TB2 TERMINAL BLOCK	TRX96	TRX96	TRX96	TRX96	TRX96	TRX96	TRX96	TRX96
	TC1 THERMOCOUPLE	TC412X1A	TC412X1A	TC412X1A	TC412X1A	TC412X1A	TC412X1A	TC412X1A	TC412X1A




WIRING DIAGRAM


4X16 SEGMENT PROGRAMMABLE CONTROL

DIAGRAM COMPONENT LIST

REF NO.	DESCRIPTION	F30430CM	F30430CM-33	F30430CM-33-60	F30430CM-40	F30430CM-40	F30430CM-40	F30430CM-40
B1&B2	BLOWER FAN	FA1262X1	FA1262X1	FA1262X1	FA1262X1	FA1262X1	FA1262X1	FA1262X1
CA1	CAPACITOR	CA1249X1	CA1249X1	CA1249X1	CA1249X1	CA1249X1	CA1249X1	CA1249X1
CB1	CIRCUIT BREAKER	SWX103	SWX103	SWX103	SWX103	SWX103	SWX103	SWX103
CN1	CONTROL	CN71X90	CN71X90	CN71X90	CN71X90	CN71X90	CN71X90	CN71X90
DS1	PILOT LIGHT, NEON	PLX82	PLX82	PLX82	PLX82	PLX82	PLX82	PLX82
FL1	FILTER, EMI	CAX99	CAX99	CAX99	CAX99	CAX99	CAX99	CAX99
H1	HEATING ELEMENT	EL412X4	EL412X4	EL412X4	EL412X4	EL412X4	EL412X4	EL412X4
H2	HEATING ELEMENT	EL412X5	EL412X5	EL412X5	EL412X5	EL412X5	EL412X5	EL412X5
H1	HEATING ELEMENT	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6
H2	HEATING ELEMENT	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6	EL412X6
RY1	SOLID STATE RELAY	RYX37	RYX37	RYX37	RYX37	RYX37	RYX37	RYX37
RY2	SOLID STATE RELAY	RYX37	RYX37	RYX37	RYX37	RYX37	RYX37	RYX37
RY3	SOLID STATE RELAY	RYX37	RYX37	RYX37	RYX37	RYX37	RYX37	RYX37
RY4	SOLID STATE RELAY	RYX37	RYX37	RYX37	RYX37	RYX37	RYX37	RYX37
S1	RELAY, DPST, N.O.	SWX143	SWX143	SWX143	SWX143	SWX143	SWX143	SWX143
S2	DOOR SWITCH	Q4246	Q4246	Q4246	Q4246	Q4246	Q4246	Q4246
TB1	TERMINAL BLOCK	TRX178	TRX178	TRX178	TRX178	TRX178	TRX178	TRX178
TB2	TERMINAL BLOCK	TRX178	TRX178	TRX178	TRX178	TRX178	TRX178	TRX178
TC1	THERMOCOUPLE	TC412X1A	TC412X1A	TC412X1A	TC412X1A	TC412X1A	TC412X1A	TC412X1A



WIRING DIAGRAM



COMMUNICATION CABLE WIRING

Important

For your future reference and when contacting the factory, please have the following information readily available:

Model Number: _____

Serial Number: _____

Date Purchased: _____

The above information can be found on the dataplate attached to the equipment. If available, please provide the date purchased, the source of purchase (manufacturer or specific agent/rep organization), and purchase order number.

IF YOU NEED ASSISTANCE:

LABORATORY PARTS and SERVICE

Phone: 800/438-4851

FAX: 828/658-2576

TECHNICAL SUPPORT

Phone: 800/438-4851

Thermo Fisher Scientific Inc.

275 Aiken Road
Asheville, NC 28804
United States

www.thermofisher.com

